


HWL-LI CORE BARREL SPARE PARTS KIT



	ITEM DESCRIPTION	PART NUMBERS
1-23	HWL-LI CORE BARREL SPARE PARTS KIT	18-00-140
1	SPEARHEAD POINT	16-03-001
2	COMPRESSION SPRING	16-03-002
3	DETENT PLUNGER	16-03-003
4	SOLID DOWELL 7/16" x 1"	16-03-005
5	SPRING DOWELL 1/2" x 2 3/4" - 2 NOS.	18-03-003
6	HWL-LI LATCH - 2 NOS.	18-03-005
7	SOLID DOWELL 1/2" x 2 1/8"	18-03-006
8	STAINLESS STEEL BALL 22 mm	16-03-014
9	LANDING INDICATOR BUSH O RING	16-03-016
10	LANDING INDICATOR BUSH	16-03-015
11	LANDING SHOULDER	18-03-008
12	ADJUSTING HEX NUT	18-03-010
13	SHUT OFF VALVE - 2 NOS.	18-03-012
14	THRUST BEARINGS - 2 NOS.	18-03-014
15	BEARING SPINDLE	18-03-016
16	THRUST BEARING - 1 NOS.	18-03-017
17	NYLOCK NUT, 1" UNC	18-03-019
18	GREASE FITTING	16-03-024
19	RING STOP	18-03-025
20	CORE LIFTER	18-03-026
21	CORE LIFTER CASE	18-03-027
22	RING LANDING	18-02-003
23	STABILIZER RING	18-02-006