


HMLC CORE BARREL SPARE PARTS KIT



	ITEM DESCRIPTION	PART NUMBERS
1-8	HMLC CORE BARREL SPARE PARTS KIT	66-00-140
01	HMLC OIL SEAL	66-01-004
02	HMLC BALL BEARING	66-01-006
03	HMLC THRUST BEARING	66-01-007
04	HMLC OIL SEAL	66-01-009
05	HMLC OIL SEALS – 2 NOS.	66-03-008
06	HMLC RING STOP	66-03-016
07	HMLC CORE LIFTER	66-03-017
08	HMLC CORE LIFTER CASE	66-03-018