


**LTK48 CORE BARREL**



	ITEM DESCRIPTION	PART NUMBERS
1-20	LTK48 CORE BARREL 3.0m / 10 ft	51-00-100
1-20	LTK48 CORE BARREL 1.5m / 5 ft	51-00-110
1	HEAD	51-02-001
2	LOCK NUT	51-03-008
3	SPINDLE ASSEMBLY	51-03-003
4	VALVE ADJUSTING WASHER - 2 NOS.	51-03-004
5	SHUT OFF VALVE	51-03-005
6	THRUST BEARING	51-03-001
7	BEARING SPINDLE	51-03-014
8	HANGER BEARING	51-03-012
9	COMPRESSION SPRING	51-03-016
10	NYLOCK NUT , 5/8"UNC	14-03-017
11	INNER TUBE CAP ASSEMBLY	51-03-009
12	STAINLESS STEEL BALL 22mm	51-03-014
13	CHECK VALVE BODY	51-03-004
14	GREASE FITTING	16-03-024
15	INNER TUBE 3.0m / 10ft	51-03-010
15	INNER TUBE 1.5m / 5 ft	51-03-011
16	RING STOP	51-03-012
17	CORE LIFTER	51-03-013
18	CORE LIFTER CASE	51-03-014
19	OUTER TUBE 1.5m / 5 ft	51-02-002
19	OUTER TUBE 3.0m / 10 ft	51-02-003
20	THREAD PROTECTOR	51-02-004