


**LTK60 CORE BARREL**



	ITEM DESCRIPTION	PART NUMBERS
1-20	LTK60 CORE BARREL 3.0m / 10 ft	49-00-100
1-20	LTK60 CORE BARREL 1.5m / 5 ft	49-00-110
1	HEAD	49-02-001
2	LOCK NUT	14-03-008
3	SPINDLE ASSEMBLY	49-03-003
4	VALVE ADJUSTING WASHER, 2 NOS.	49-03-004
5	SHUT OFF VALVE	49-03-005
6	BALL THRUST BEARING	49-03-001
7	BEARING SPINDLE	14-03-014
8	HANGER BEARING	14-03-012
9	COMPRESSION SPRING	14-03-016
10	SELF LOCK NUT	14-03-017
11	INNER TUBE CAP ASSEMBLY	49-03-009
12	STEEL BALL, 3/4"	16-03-014
13	CHECK VALVE BODY	49-03-004
14	GREASE FITTING	16-03-024
15	INNER TUBE 3.0m / 10ft	49-03-010
15	INNER TUBE 1.5m / 5 ft	49-03-011
16	RINGSTOP	49-03-012
17	CORE LIFTER	49-03-013
18	CORE LIFTER CASE	49-03-014
19	OUTER TUBE 1.5m / 5 ft	49-02-002
19	OUTER TUBE 3.0m / 10 ft	49-02-003
20	THREAD PROTECTOR	49-02-004