


NMLC CORE BARREL SPARE PARTS KIT



	ITEM DESCRIPTION	PART NUMBERS
1-8	NMLC CORE BARREL SPARE PARTS KIT	68-00-140
01	NMLC OIL SEAL	68-01-004
02	NMLC BALL BEARING	68-01-006
03	NMLC THRUST BEARING	68-01-007
04	NMLC OIL SEAL	68-01-009
05	NMLC OIL SEALS – 2 NOS.	68-03-008
06	NMLC RING STOP	68-03-016
07	NMLC CORE LIFTER	68-03-017
08	NMLC CORE LIFTER CASE	68-03-018